

Alarm Panels

An alarm panel signals the operator when the manifold begins to draw from the secondary bank, or when the cylinder pressure declines to a preset value. The manifold must be equipped with a pressure switch to operate the alarm panel.

ORDERING INFORMATION

Tube	Size (in)	Enclosure	Part Number
w/ Horn	10" x 10" x 4"	Steel	278-330991
w/ Buzzer	10" x 10" x 4"	Steel	278-330992
w/ Buzzer	9" x 3" x 4"	Fiberglass	278-422664

